MINI KICK Table Football Game



ASSEMBLY INSTRUCTIONS

Please keep for future reference Adult Assembly Required

0319

PARTS IDENTIFIER


Parts not drawn to size

1	2	3	4	5
		S.		Ċ
Side Panel 2pcs	End Panel 2pcs	Playfield 1pc	Support Brace 1pc	Leg 4pcs
6	7	8	9	10
)			0
Support Rod 1pc	Nut 2pcs	3-Player Rod 3pcs	3-Player Rod 3pcs	Bumper 12pcs
11	12	13	14	15
		D	Carleson and	
Washer 24pcs	Handle 6pcs	Rod Cap 6pcs	Scorer 2pcs	Screw 4pcs
16	17	18	19	20
O	\bigcirc		-	
Bolt 20pcs	Washer 20pcs	Goal 2pcs	Screw 4pcs	6mm Allen Key 2pcs
21	22			
	\bigcirc			
4mm Allen Key 1pc	Ball 2pcs			


ASSEMBLY INSTRUCTIONS

Please keep these instructions for future reference. Adult assembly required. This table is not a toy & is intended for use under the supervision of adults. Suitable for 8 years & above.


- 1. Find a clean & level place to begin the assembly of your MINI KICK table football game. It will be assembled upside down & then turned over onto its legs once complete.
- 2. Remove all parts from the box & verify you have all the pieces that are listed in the 'Parts Identifier'. Carefully cut or tear the four corners of the box so that the bottom can be used as your work surface. Save all packing materials until the parts have been inspected & the table is assembled.
- 3. Place one side panel #1 upside down with the finished side facing out the ball entry hole will be closest to the floor. To ease assembly push the bumpers & washers ((#10 & #11) onto the rods, up against the men. Insert the rods through the holes in the side panel. Alternate the black player rods with the white player rods. The handle end of the rod has a hole close to the end of the rod. There will be three handles (one team) on each side of the table. Remember that the goalie rod is always in your left hand when the table is in the upright position you are working upside down so it will be opposite during assembly.




- 4. Once you are sure you have all the players set up correctly, slide the other side panel #1 on to the other end of the rods.
- 5. Set the playfield #3 on top of the assembly with the graphics facing down & insert it into the grooves on the side panels.
- Place the playfield support brace #4 on the bottom of the playfield, then slide the support rod #6 through the side panel & into the groove of the support brace. Secure with finishing nut #7. DO NOT TIGHTEN AT THIS TIME.



- 7. Attach the two end panels #2 using the bolts #16 & washers #17 as shown below. Tighten all hardware at this time making sure that the end panels are straight. DO NOT OVERTIGHTEN.
- 8. Attach the goals #18 to the end panels with the screws #19.
- 9. Attach the legs using the bolts #16 & washers #17.



- 10. Slide the handles #12 onto the end of the rods with the holes close to the end. Slide the rubber end caps #13 on to the other ends of the rods.
- 11. Attach the scorers #14 to the end panels & secure with the screws # 15.



You are now ready to play!



For sales & service contact: Mightymast Leisure Ltd 58 Bentwaters Park, Rendlesham Woodbridge, Suffolk. IP12 2TW UK Tel: +44 (0)1394-460896 www.mightymast.com info@mightymast.com

